



WAMA ELECTRONICS TECH CO.,LTD_

Model:WACH06

Thank you to purchase our li-ion battery charger, use that product for the exactitude. Use that product for the exactitude, The usage invites you the careful reading this manual before. And appropriate takes care of, in order to check.

1. Main characteristic

- suits the li- ion R123A with 16340 batteries refresh.
- can the independent battery in single stanza refresh, or 2 the section refresh at the same time.
- a color LED instructions light, the red bright hour is a battery refresh, green light bright the hour instructions for the power supply light or batteries complete to refresh.
- exchanges electric voltage inputs to adapt to the scope breadth;The features is beautiful cleverly made.

2. Technique specification

In put: AC100V \sim a 50 Hzs/ a 5 Ws

Out put: DC4.2V 350mA

Usage environment temperature:0 °C -40 °C

Weight: 120g

3. the method that refresh

Show according to the plus or minus pole in battery in charger diagram, and match with the plus or minus pole standard of the refresh battery, putting into the battery, then proceeding to connect to switch on electricity the source. Battery above of the hour of bright red light in the light of designation means in to refresh the appearance, bright green light the hour means that the battery has refreshed to complete, commendable bottom battery usage.

4.Refresh time

Refreshing the front please estimate in advance to refresh time, in order to prevent battery is placed over a long period of time in charger inside, affecting the battery use, the capacity(if 2 batteries refreshes at the same time, the capacity need to be added mutually) \div of the battery refreshes battery 350 mAs= refresh of estimate time.(hour)

5. Announcements

- A, refresh the process the inside must not pack to unload or loosen to move the battery arbitrarily, in order to prevent the influence refreshes the result.
- B, that charger does not connect to switch on electricity the source circumstance bottom can't deposit the battery.
- C, refresh the battery will have fever to belong to slightly normal like of now.
- D, refresh please within the scope of 0 °C s-40 °C s of usage.
- E, can refresh not the battery please do not refresh, may leak liquid or blowouts otherwise.

F, can't at damp, the local usage of many dusts with deposit.

G, can't keep shooting in the sunlight, stove etc. heat place usage with deposit.

H, limit the indoors usage only

.

6, warning:

- * if meet When the child demand use, teach right operation method to child, combine to inspect its operation method in its use process.
- * please not to put the charger to put in electric outlet at the place that infant can touch, to do not need the occurrence dangerous..